



3300 Series



contents 2 3 5 6 7 Features **Specifications** 3340. 3330F **Dimensions Range Diagram** Load Chart **features** 3330FL • 4 models ... 8 9 3330F: 8.5T (7.7mt) 3-section boom with Dimensions 25 ft. 2 in. (7.6m) Tip Height 3340. **Range Diagram** 3330FL: 8.5T (7.7mt) 3-section boom with 33 ft. 6 in. (10.2m) Tip Height 10 Load Chart 3339: 9.0T (8.1mt) 3-section boom with 38 ft. 2 in. (11.6m) Tip Height 3339 3340B: 10.5T 11 (9.5mt) 3-section Dimensions boom with 38 12 ft. 2 in. (11.6m) **Range Diagram Tip Height** 13 Load Chart SHUTTLELIFT • 6 ft. (1.8m) fixed 3340B extension (3330F / FL) 14 and 12 ft. (3.6m) **Dimensions** offsettable swingaway 15 extension (3339 & 3340B) **Range Diagram** 16 • 70 bhp (52.2 kW) GM EFI dual fuel engine or Load Chart 99 bhp (73.8 kW) Cummins diesel engine



*Product may be shown with optional equipment.

www.manitowoccranegroup.com

features

2



 Single position oblique style outriggers

 Narrow width for inside aisle way usage



Standard: Cummins QSB 3.3L turbocharged diesel rated @ 99 bhp (73.8kW) @ 2600 rpm.



Standard:	Open air cab shell w/overhead safety
Optional:	glass Closed cab with hinged door, heater, and defroster



Standard:	21 ft. (6.4m) main boom on the 3330F
	30 ft. (9.1m) main boom on the 3330FL
	32 ft. 10 in. (10.0m) main boom on the 3339 &
	3340B
Ontional	Manual 4th main boom section adds 10 ft (3 0r

Optional: Manual 4th main boom section adds 10 ft. (3.0m) additional main boom length on 3330F and 3330FL only.



Standard: 4-wheel coordinated steer Optional: 2-wheel, 4-wheel, and crab steer (std. on 3339) Standard: 2-wheel, 4-wheel, and crab steer with self alignment (3340B)

specifications

Superstructure

📲 Boom

 $3330F; 9 \mbox{ ft}. 8 \mbox{ in}. - 21 \mbox{ ft}. 2 \mbox{ in}. (2.9 \mbox{ m} - 6.5 \mbox{m}) \mbox{ three- section full power boom.}$

Maximum tip height: 25 ft. 2 in. (7.6m)

3330FL: 12 ft. 8 in. – 30 ft. 2 in. (3.8m – 9.2m) three- section full power boom.

Maximum tip height: 33 ft. 6 in. (10.2m)

3339 & 3340B: 13 ft. 10 in. – 32 ft. 10 in. (4.2m – 10.0m) threesection full power boom. Maximum tip height: 38 ft. 2 in. (11.6m)

***Optional Boom**

3330F & 3330FL: Manual 4th main boom fly section

*Boom Extension

3330F & 3330FL: 6 ft. (1.8m) fixed pin on extension 3339 & 3340B: 12 ft. (3.6m) offsettable extension 12-18 ft. (3.6-5.4m) telescopic offsettable extension

🕽 Boom Nose

3330F / FL: Single sheave non-pivoting 3339 & 3340B only: Single sheave, 3-position (0°, + 30°, + 80°) pivoting boom nose for minimizing head space requirements. Lowers head height 10.5 in. (0.26m) when nose is pivoted fully forward.

Boom Elevation

Single double acting hydraulic cylinder with integral holding valve.

Elevation: 0° to 60° for the 3330F & 3330FL 0° to 72° for the 3339 & 3340B

📕 Anti-Two Block Device

Standard anti-two block device, when activated, provides an audible warning to the crane operator and disengages all crane functions whose movement can cause two-blocking.

Load Indicator

A simple, effective, and easy to use load indicating system used in conjunction with the anti-two block system to assist the operator in efficient operation of the unit within the limits of the load chart. The display panel displays the hook load and warns the operator when a preset load capacity is exceeded. The warning is an audible alarm. In conjunction with the load display panel (receiver), there is a wireless transmitter and load sensing pin attached to the boom head that transmits the hook load to the display panel.

Arrow Transfer (RCL) *Rated Capacity Limiter (RCL)

Similar to the Load Indicator, but stops the telescope out and boom lift down function when a load limit is exceeded. Uses a similar display panel with the addition of displaying boom angle and boom length read outs on the panel.

🞩 *Load Moment Indicator (LMI)

3

Digital display of boom angle, boom length, boom radius, capacity, and allows for operator in-put to set the limits based on load chart. Displays color coded light bar and audible alarm with function cutout if load exceeds entered parameters.

1 Swing

Ball bearing swing circle with 360° continuous rotation. Hydraulic driven worm gear and pinion. Maximum speed: 2.05 rpm



3330F & 3330FL: (2) gear pumps

3339 & 3340B: Variable displacement piston pump and piggyback gear pump.

Combined flow: 28.5gpm (107.9Lpm)

Maximum system operating pressure: 3600 psi

3330F & 3330FL: Six section valve bank mounted in dash panel with direct mechanical linkage for low effort lever control.

3339 & 3340B: Six section valve bank chassis mounted; operated via dash mounted, pilot pressure hydraulic joysticks.

Return line filter with full flow by-pass protection and service indicator.

23.5 gallon (89 L) hydraulic reservoir with sight level gauge and steel side plating to guard against side impact damage.

Hoist Specifications

3330F / FL: Worm drive with counter-balance valving. Equal speed power up and down.

3339 & 3340B: Piston motor drive w/spring applied/hydraulic released brake.

Drum Diameter:	
3330F / FL:	9.69 in. (0.24m)
3339 & 3340B:	10.63 in. (0.27m)
Maximum Single Line Pull:	
3330F / FL:	10,700lb (4 854kg)
3339 & 3340B:	14,000lb (6 350 kg)
Maximum Single Line Speed:	
3330F / FL:	88 FPM (26.8m / min)
3339 & 3340B:	120FPM (36.6m / min)
Maximum Permissible Single Lir	ne Pull:

aximum Permissible Single Line Puli: 3330F / FL : 8,500lb (3 855 kg) (1/2" [12.7mm] Python Ultra XIPS) 3339 & 3340B: 10,000lb (4 536kg) (9/16" [14.0mm] EEIPS)

Rope Length :

3330F / FL: (3-section boom)	97 ft. (29.6m)
(4-section boom)	130 ft. (39.6m)
3339 & 3340B:	120 ft. (36.6m)

*Denotes optional equipment



specifications

Carrier

Frame

High strength alloy steel constructed with integral outrigger housings; front and rear lifting, towing, and tie-down lugs. 42 ft.² carrydeck size with 14,000 lb (6 350kg) carrying capacity (3330F / FL / 3339) and 17,000 lb (7 711kg) carrying capacity (3340B). Deck coated with anti-skid treatment.

L-Outriggers

3330F, 3330FL & 3339: Front and rear oblique type beams at all four corners with integral holding valves. Outrigger pads form an integral part of the beam.

3340B: Hydraulic telescoping beam with oblique type jack provides extended and down and retracted and down lifting capacities. Integral holding valves on both beam and jack.

Uutrigger Controls

3330F, 3330FL & 3339: Lever controls located on dash panel which operate the beams in pairs from side to side.

3340B: Two switch operation mounted on dash panel. One -3position rocker switch to select all beams / jacks, left beams / jacks only, or right beams / jacks only. Separate -4- way toggle switch to activate beams out / in and jacks down / up. Level bubble indicator located inside operators compartment. *Independent outrigger controls available as an option.

Std. Engine (Tier III)

Cummins QSB 3.3L turbo-charged diesel rated @ 99 bhp (73.8kW) @ 2600 rpm.

*Optional Engine

G.M. 3.0L EFI dual fuel (gasoline / L.P.) rated @ 70 bhp (52.2kW) @ 2600 rpm.

Operators Control Station

Frame mounted, open air style control station with cab shell. Includes all crane functions, driving controls, and overhead safety glass. Other standard equipment include a durable weather resistant seat with seat belt, hourmeter, sight level bubble, and fire extinguisher. The dash panel includes engine oil pressure gauge, engine water temperature gauge, fuel gauge, transmission low oil and high temperature warning lights, low battery warning light, and brake system low pressure warning light. The LSI (load indicator) receiver is mounted to the top of the dash and provides warning for A2B and exceeded load capacity.

*Operators Control Station Enclosed

Includes the standard cab shell with the addition of front and rear glass. Hinged full door with sliding glass.

Front windshield wiper and heater and defroster is included.

Fuel Tank Capacity

18.5 gallon (70 L) all steel construction with steel side plate to guard against side impact.

4 Electrical System

One 12V maintenance free battery, 820CCA @ 0°. Jump start connections 63 amp alternator.

Drive

4 x 2 – Front axle drive with planetary hubs and limited slip Differential.

T Steer

- 3330F / FL: 2-wheel, 4-wheel steer
- 3339: 3340B:
- 2-wheel, 4-wheel w/crab steer
 - 2-wheel, 4-wheel, and crab steer w/ electronic self alignment.

O Transmission

- 33330F / FL & 3339: Clark synchromesh -4- speeds forward and reverse with stalk mounted forward/reverse selector.
- 3340B:
- Clark powershift -4- speeds forward and reverse. Stalk mounted shifter on left side of steering column.

<u></u> → Axles

Front: Carraro planetary drive/steer with internal multi-wet-disc brakes and limited slip differential.

Rear: Fabricated non-drive steer with disc brakes



10.00 x 15 14PR pneumatic



Hydraulic actuated internal wet-disc service brakes acting on all four wheels. A dash mounted toggle switch activates the dry disc parking brake on the transmission output yoke with a dash warning light.

Suspension

Front: Rigid mounted to frame. Rear: Rigid mounted to frame

Lights

Recessed mounted, includes head, tail, rear work, stop, and turn signals.

Maximum Speed

22 MPH (35.6km/h)

Gradeability**

3330F / FL & 3339: 57%....no load 31%....12,000lb (5 443kg) load

3340B: 68%....no load 40%....20,000lb (9 072kg) load

G.V.W.

3330F:	13,400 lb. (6 078 kg)
3330FL:	15,180 lb (6 885 kg)
3339:	15,800 lb (7 167 kg)
3340B:	16,600 lb (7 530 kg)

Miscellaneous Standard Equipment

Single sheave, "Quick Reeve" style hookblock.; 3330F/ FL 8.5T (8.0mt); 3339: 9T (8.1mt); 3340B10.5T (10mt). Back-up alarm.

*Denotes optional equipment **Theoretical







3300 Series



OPERATING RADIUS IN FEET FROM AXIS OF ROTATION

3300 Series

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

3330F

RADIUS	4-SECTI	3-SECTION BOOM OR 4-SECTION BOOM WITH 4TH RETRACTED				RADIUS	4-SECTION BOOM WITH 4TH EXTENDED				MAIN	JIB STRUCTURAL	CAPACITIES (lbs.)
(ft)	ON OUTRIG	GERS (lbs)	ON RUBE	BER (Ibs)		(ft)	ON OUTRIG	GERS (lbs)	ON RUB	BER (lbs)	BOOM	3-SECTION BOOM OR	
	F/R	360°	F/R	360°			F/R	360°	F/R	360°	ANGLE (deg)	4-SECTION BOOM WITH 4TH RETRACTED	4-SECTION BOOM WITH 4TH EXTENDED
5.0	17000	* 17000	10000	10000		5.0	6100	6100	6100	6100	,		0500
6.0	* 15700	* 14400	10000	7450	BOOM	6.0	6100	6100	6100	6100	60	3500	3500
8.0	* 12400	10800	7150	4400	8	8.0	5300	5300	5300	5250	55	3325	3325
10.0	10200	8600	4700	2950	MAIN	10.0	4700	4700	4700	3750	50	3150	3150
12.0	8500	7000	3400	2175	M	12.0	4400	4400	3800	2450	45	3000	3000
14.0	7200	5400	2650	1700		14.0	4400	4400	2900	1875	40	2875	2875
16.0	6100	4300	2150	1325		16.0	4400	4400	2325	1525	35	2800	2800
18.0	5000	3550	1775	1100	1	18.0	4400	4100	1900	1225	30	2700	2700
20.0	2700	2700	1525	950	Λ	20.0	4300	3150	1600	1000	25	2600	2600
22.0	2600	2600	1350	825	$ \rangle$	22.0	3700	2700	1375	850			
24.5	2200	2200	1150	675	$ \rangle$	24.5	3100	2300	1200	700	20	2500	2500
26.0	-	-	- 1	-		26.0	2700	2125	1100	650	15	2400	2400
28.0	-	-	-	-	띡	28.0	2500	1900	975	575	10	2325	2325
30.0	-	-	-	-	5	30.0	2300	1700	850	475	5	2250	2250
31.0	-	-	-	-		31.0	2200	1625	800	425	0	2200	2200

*LIMIT RATINGS TO 11,800 LBS WHEN 3RD SECTION IS EXTENDED ANY AMOUNT.

JIB CAPACITY IS LIMITED BY BOTH STRUCTURAL CAPACITY CHART AND MAIN CAPACITY CHART.

SHADED AREAS ARE GOVERNED BY STRUCTURAL STRENGTH, DO NOT RELY ON TIPPING.



REDUCTION CHART								
	FROM MAIN BOOM RATINGS	FROM JIB RATINGS						
MAIN BLOCK	140 lbs	N/A						
HOOK & BALL	100 lbs	100 lbs						
JIB, STOWED	0 lbs	N/A						
JIB, DEPLOYED	150 lbs	0 lbs						



- The rated loads are the maximum lift capacities as determined by operating radius, boom extension and boom angle. The operating radius is the horizontal distance from a projection of the axis of rotation to the supporting surface, before loading, to the center of vertical hoist line or tackle with load applied.
 - The rated loads shown on outriggers do not exceed 85% of actual tipping. The rated loads shown on rubber do not exceed 75% of actual tipping. These ratings are based on freely suspended loads with the crane leveled, standing on a firm, uniform supporting surface. Practical working loads depend on supporting surface, operating radius and other factors affecting stability. Hazardous surroundings, climatic conditions, experience of personnel and proper training must all be taken into account by the operator.
 - The weights of all load handling devices such as hooks, hook blocks, slings, etc., except the hoist rope, shall be considered as part of the load. See reduction chart.
 - Ratings on outrigggers are for either outriggers fully extended and down or fully retracted and down. Ratings for outriggers fully retracted and down will apply for any intermediate outrigger setting.

- 5) Ratings on rubber depend on tire capacity, condition of tires and proper inflation pressure (100 psi). Loads on rubber may be transported at a maximum speed of 2.5 mph on a smooth hard level surface with boom retracted to the shortest length possible and centered over front.
- 6) For operating radius not shown, use load rating of next larger radius.
- The maximum combined total boom and deck load is 12000 lbs. The maximum deck load only is 14000 bs.
- Do not induce any external side loads to boom or jib.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

3)





3300 Series



OPERATING RADIUS IN FEET FROM AXIS OF ROTATION



	÷		4	h	
1	1	L		U	

	3-SE	CTION BOOM OR 4-SECTIC	ON BOOM WITH 4TH RETRA	CTED				4	SECTION BOOM W	ITH 4TH	EXTENDED	
OPERATING RADIUS	ON OUT	RIGGERS	ON R	ON RUBBER		OPERATING RADIUS	ON C	UTRIGGER	S		ON RI	JBBER
	FRONT	360°	FRONT	360°			FRONT		360°		FRONT	360°
5.0 ft	17000 lbs	17000 lbs	10000 lbs	10000 lbs		5.0 ft	-					
6.0 ft	15700 lbs	14400 lbs	9500 lbs	8200 lbs	1	6.0 ft	-		-			
8.0 ft	12400 lbs	10800 lbs	8000 lbs	5600 lbs		8.0 ft	4900 lbs	4	900 lbs		4900 lbs	4900 lbs
10.0 ft	10200 lbs	8500 lbs	5400 lbs	3800 lbs		10.0 ft	4300 lbs	4	300 lbs		4300 lbs	4250 lbs
12.0 ft	8500 lbs	6950 lbs	3800 lbs	2700 lbs	Σ	12.0 ft	3800 lbs	3	800 lbs		3800 lbs	3300 lbs
14.0 ft	7100 lbs	5800 lbs	2750 lbs	1950 lbs	8	14.0 ft	3400 lbs	3	400 lbs		3400 lbs	2600 lbs
16.0 ft	6000 lbs	4650 lbs	2150 lbs	1450 lbs	MAIN BOOM	16.0 ft	3100 lbs	3	100 lbs	1	2900 lbs	2100 lbs
18.0 ft	5200 lbs	3800 lbs	1800 lbs	1150 lbs	1 E	18.0 ft	2900 lbs	2	900 lbs	:	2400 lbs	1700 lbs
20.0 ft	4450 lbs	3150 lbs	1500 lbs	950 lbs	Σ	20.0 ft	2900 lbs	2	900 lbs		1950 lbs	1350 lbs
22.0 ft	3800 lbs	2700 lbs	1300 lbs	800 lbs		22.0 ft	2900 lbs	2	900 lbs		1600 lbs	1050 lbs
24.0 ft	3300 lbs	2350 lbs	1100 lbs	650 lbs		24.0 ft	2900 lbs	2	650 lbs		1350 lbs	850 lbs
26.0 ft	2900 lbs	2050 lbs	950 lbs	550 lbs		26.0 ft	2900 lbs	2	300 lbs		1100 lbs	700 lbs
27.0 ft	2750 lbs	1900 lbs	850 lbs	500 lbs		27.0 ft	2900 lbs	2	150 lbs		1000 lbs	650 lbs
28.0 ft	2525 lbs	1775 lbs	800 lbs	475 lbs	Ν	28.0 ft	2750 lbs	2	000 lbs		950 lbs	600 lbs
30.0 ft	2275 lbs	1600 lbs	700 lbs	400 lbs	$ \rangle$	30.0 ft	2450 lbs	1	800 lbs		800 lbs	500 lbs
32.0 ft	2025 lbs	1425 lbs	600 lbs	325 lbs	$ \rangle$	32.0 ft	2200 lbs	1	600 lbs		700 lbs	400 lbs
33.5 ft	1875 lbs	1300 lbs	525 lbs	275 lbs	$ \rangle$	33.5 ft	1950 lbs	1	400 lbs		625 lbs	325 lbs
36.0 ft	-	-			\	36.0 ft	1750 lbs	1	250 lbs		550 lbs	250 lbs
38.0 ft	-	-				38.0 ft	1625 lbs	1	125 lbs		475 lbs	225 lbs
40.0 ft	-	-				40.0 ft	1475 lbs	1	025 lbs		400 lbs	200 lbs
42.0 ft	-	-			l	42.0 ft	1350 lbs		925 lbs		350 lbs	150 lbs
43.0 ft	-	-	-		۹ſ	43.0 ft	1300 lbs		375 lbs		325 lbs	125 lbs
JIB STRUC	JIB STRUCTURAL CAPACITIES @ MAIN BOOM ANGLE (ALSO DO NOT EXCEED CAPACITIES IN ABOVE CHART)]	JIB STRUC	TURAL CAPACITIES @	MAIN BOOI	ANGLE (ALSO DO	NOT EX	XCEED CAPACITIE	S IN ABOVE CHART)
0°	15°	30°	45°	60°	1	0°	15°		30°		45°	60°
2200 lbs	2400 lbs	2700 lbs	3000 lbs	3500 lbs		2000 lbs	2100 lb	s	2200 lbs		2600 lbs	3400 lbs

SHADED AREAS ARE GOVERNED BY STRUCTURAL STRENGTH. DO NOT RELY ON TIPPING

OPERATION OF THIS EQUIPMENT IN EXCESS OF RATING CHARTS AND DISREGARD OF INSTRUCTIONS IS DANGEROUS AND VOIDS WARRANTY.



REDUCTION CHART								
	FROM MAIN BOOM RATINGS	FROM JIB RATINGS						
MAIN BLOCK	140 lbs	N/A						
HOOK & BALL	100 lbs	100 lbs						
JIB, STOWED	0 lbs	N/A						
JIB, DEPLOYED	150 lbs	0 lbs						



1. The rated loads are the maximum lifting capacities as determined by operating radius only. Any combination of boom lengths and angles may be used to obtain operating radius. The operating radius is the horizontal distance from a projection of the axis of rotation to the supporting surface, before loading, to the center of vertical hoist line or tackle with load applied.

 \overline{M}

3330F

11

Ĺ

- 2. The rated loads shown on outriggers do not exceed 85% of actual tipping. The rated loads shown on rubber do not exceed 75% of actual tipping. These ratings are based on freely suspended loads with the machine leveled, standing on a firm, uniform supporting surface. Practical working loads depend on supporting surface, operating radius, and other factors affecting stability. Hazardous surroundings, experience of personnel and proper handling must all be taken into account by the operator.
- 3. The weights of all load handling devices, such as hooks, hook blocks, slings, etc., except the hoist rope, shall be considered as part of the load. See reductrion chart.
- 4. Ratings on outriggers are with outriggers fully extended.
- 5. Ratings on rubber depend on tire capacity, condition of tires, and proper inflation pressure (100 psi). Loads on rubber may be transported at a maximum speed of 2.5 mph on a smooth hard level surface with boom retracted to the shortest length possible and centered over front.
- 6. For operating radius not shown, use load rating of the next larger radius.
- 7. The maximum combined total boom and deck load is 12,000 lbs. For deck loads only, the maximum load is 14,000 lbs with 10:00 x 15 tires. Tire inflation at at 100 psi.
- 8. Do not induce external side loads to boom or jib.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.



3339





3339



3300 Series

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

3339

			ON OUTRIC	ON RUBBER (Ibs)			
	RADIUS (ft)	F/	R	36	:0°	F/R	360°
	(1)		BOOM EXTENDED	BOOM RETRACTED	BOOM EXTENDED	ANY BOOM	ANY BOOM
	5.0	18000	14700	18000	14700	11500	9400
	6.0	15700	14400	15000	14400	10000	7500
	8.0	12200	12200	11400	11400	8100	5040
	10.0	10200	10200	9100	9100	5480	3530
Σ	12.0	8400	8400	7600	7600	3920	2590
<u> </u>	14.0	-	7200	· ·	6500	3040	1970
<u>ă</u>	16.0	-	6200	-	5310	2420	1560
M AIN BOOM	18.0	-	5400	-	4340	1970	1250
Σ	20.0	-	4830	-	3610	1640	1020
	22.0	-	4000	-	3030	1370	850
	24.0	-	3480		2590	1160	710
	26.0	-	3020	-	2250	990	590
	28.0	-	2680	-	2010	830	490
	31.0	-	2270	-	1740	650	360
	34.0	-	1960	-	1500	510	250
	36.0	-	1770	-	1350	430	180
	38.0	-	1590	-	1200	350	130
<u> </u>	40.0	-	1420	-	1050	280	80
	42.0	-	1270		930	210	60
	44.0	-	1200	-	880	190	40
	46.0	-	1160	-	820	170	20
	48.0	-	1110		760	140	0

	JIB STRUCTURAL CAPACITIES (lbs)									
MAIN BOOM ANGLE		12 FT JIB		18 FT JIB						
(deg)	0° OFFSET	15' OFFSET	30' OFFSET	0' OFFSET	15' OFFSET	30' OFFSET				
72	7500	5100	3500	4000	3300	2300				
70	7000	4800	3400	3750	3100	2200				
65	5700	4100	3100	3200	2700	2000				
60	4500	3500	2800	2800	2400	1850				
55	3500	3000	2550	2450	2150	1700				
50	2800	2500	2300	2150	1950	1600				
45	2300	2200	2000	1900	1750	1500				
40	2000	1900	1800	1700	1600	1400				
35	1775	1675	1600	1525	1450	1350				
30	1600	1500	1400	1400	1300	1300				
25	1450	1400	-	1275	1200	-				
20	1350	1350	-	1175	1125	-				
15	1300	1300	-	1100	1100	-				
10	1275	-	-	1050	-	-				
5	1225	-	-	1025	-	-				
0	1200	-	-	1000	-	-				

13



REDUCTION CHART						
	FROM MAIN BOOM RATINGS		FROM JIB RATINGS			
MAIN BLOCK	140 lbs		N/A			
HOOK & BALL	100 lbs		100 lbs			
JIB, STOWED	0 lbs		N/A			
JIB, DEPLOYED	450 lbs		0 lbs			
RIGGING CHART						
1-PART 0-10000 lbs		2-PART 0-18000 lbs				
WIRE ROPE: 9/16 inch diameter Min. breaking strength 35000 lbs.						

- The rated loads are the maximum lift capacities as determined by operating radius, boom extension and boom angle. The operating radius is the horizontal distance from a projection of the axis of rotation to the supporting surface, before loading, to the center of vertical hoist line or tackle with load applied.
- 2) The rated loads shown on outriggers do not exceed 85% of actual tipping. The rated loads shown on rubber do not exceed 75% of actual tipping. These ratings are based on freely suspended loads with the crane leveled, standing on a firm, uniform supporting surface. Practical working loads depend on supporting surface, operating radius and other factors affecting stability. Hazardous surroundings, climatic conditions, experience of personnel and proper training must all be taken into account by the operator.
- The weights of all load handling devices such as hooks, hook blocks, slings, etc., except the hoist rope,shall be considered as part of the load. See reduction chart.
- Ratings on outrigggers are for outriggers fully extended.
- 5) Ratings on rubber depend on tire capacity, condition of tires and proper inflation pressure (100 psi). Loads on rubber may be transported at a maximum speed of 2.5 mph on a smooth hard level surface with boom retracted to the shortest length possible and centered over front.
- For operating radius not shown, use load rating of next larger radius.
- The maximum combined total boom and deck load is 12000 lbs. The maximum deck load only is 14000 lbs.
- 8) Do not induce any external side loads to boom or jib.

JIB CAPACITY IS LIMITED BY BOTH STRUCTURAL CAPACITY CHART AND MAIN CAPACITY CHART.

SHADED AREAS ARE GOVERNED BY STRUCTURAL STRENGTH. DO NOT RELY ON TIPPING.

OPERATION OF THIS EQUIPMENT IN EXCESS OF RATING CHARTS AND DISREGARD OF INSTRUCTIONS IS DANGEROUS AND VOIDS WARRANTY. **3300** Series



3340B



THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

3300 Series

SI-JUTTLELIFT*



3300 Series



3340B

16

		ON OUTRIGGERS (lbs)				ON RUBBER (lbs)	
	RADIUS (ft)	EXTENDED 360° RETRACTED F/R		RETRACTED 360°		F/R	360
		BOOM RETRACTED	BOOM EXTENDED	BOOM RETRACTED	BOOM EXTENDED	ANY BOOM	ANY BOOM
	4.0	21000	15000	21000	15000	11500	11500
	5.0	18000	14700	18000	14700	11500	9400
	6.0	15700	14400	14400	14400	10000	7800
	8.0	12200	12200	9400	9400	8100	5900
	10.0	10200	10200	6700	6700	6100	4100
	12.0	8400	8400	5000	5000	4600	3000
No	14.0	-	7100	-	3800	3600	2400
BO	16.0	-	6000	-	3100	2900	2000
MAIN BOOM	18.0	-	5000	-	2600	2400	1600
Ŵ	20.0	-	4300	-	2100	2000	1200
	22.0	-	3700	-	1800	1700	1050
	24.0	-	3300	-	1500	1500	950
	26.0	-	2900	-	1300	1300	800
	28.0	-	2600	-	1150	1150	700
	31.0	-	2300	-	1000	900	500
۹r	34.0	-	1975	-	850	700	350
	36.0	-	1775	-	750	600	275
	38.0	-	1575	-	625	500	200
	40.0	-	1425	-	525	425	125
	42.0	-	1300	-	425	350	75
	44.0	-	1200	-	375	300	0
	46.0	-	1100	-	325	275	0
	48.0	-	1000	-	300	250	0

	JIB STRUCTURAL CAPACITIES (Ibs)							
MAIN BOOM	12 FTJIB			18 FTJIB				
ANGLE (deg)	0 OFFSET	15 OFFSET	30 OFFSET	0 OFFSET	15 OFFSET	30 ° OFFSET		
72	7500	5100	3500	4000	3300	2300		
70	7000	4800	3400	3750	3100	2200		
65	5700	4100	3100	3200	2700	2000		
60	4500	3500	2800	2800	2400	1850		
55	3500	3000	2550	2450	2150	1700		
50	2800	2500	2300	2150	1950	1600		
45	2300	2200	2000	1900	1750	1500		
40	2000	1900	1800	1700	1600	1400		
35	1775	1675	1600	1525	1450	1350		
30	1600	1500	1400	1400	1300	1300		
25	1450	1400	-	1275	1200	-		
20	1350	1350	-	1175	1125	-		
15	1300	1300	-	1100	1100	-		
10	1275	-	-	1050	-	-		
5	1225	-	-	1025	-	-		
0	1200	-	-	1000	-	-		

JIB CAPACITY IS LIMITED BY BOTH STRUCTURAL CAPACITY CHART AND MAIN CAPACITY CHART.



SHADED AREAS ARE GOVERNED BY STRUCTURAL STRENGTH, DO NOT RELY ON TIPPING.



2) The rated loads shown on outriggers do not exceed 85% of actual tipping. The rated loads shown on rubber do not exceed 75% of actual tipping. These ratings are based on freely suspended loads with the crane leveled, standing on a firm, uniform supporting surface. Practical working loads depend on supporting surface. operating radius and other factors affecting stability. Hazardous surroundings, climatic conditions, experience of personnel and proper training must all be taken into account by the operator.

The weights of all load handling devices such as hooks, hook blocks, slings, etc., except the hoist rope. shall be considered as part of the load. See reduction chart.

3)

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and

Ratings on outrigggers are for either outriggers fully extended and down or fully retracted and down. Ratings for outriggers fully retracted and down will apply for any intermediate outrigger setting.

Ratings on rubber depend on tire 5) capacity, condition of tires and proper inflation pressure (100 psi). Loads on rubber may be transported at a maximum speed of 2.5 mph on a smooth hard level surface with boom retracted to the shortest length possible and centered over front.

- 6) For operating radius not shown, use load rating of next larger radius.
- The maximum combined total boom 7) and deck load is 12000 lbs. The maximum deck load only is 14000 bs.
- Do not induce any external side loads 8) to boom or jib.



Min. breaking strength 36750 lbs.

3300 Series

other instructional plates must be read and understood prior to operating the crane.

4)

RATING CHARTS AND DISREGARD OF INSTRUCTIONS

OPERATION OF THIS EQUIPMENT IN EXCESS OF

IS DANGEROUS AND VOIDS WARRANTY.

notes



notes

18

" SIJUTTLELIFT"

notes





Regional Headquarters Americas

Manitowoc, Wisconsin, USA Tel: +1 920 684 6621 Fax: +1 920 683 6278

Shady Grove, Pennsylvania, USA Tel: +1 717 597 8121 Fax: +1 717 597 4062

Regional Offices Americas

Brazil Alphaville

Tel: +55 11 3103 0200 Fax: +55 11 4688 2013

Mexico Monterrey Tel: +52 81 8124 0128 Fax: +52 81 8124 0129

Europe, Middle East, Africa

Algeria Hydra Tel: +21 3 21 48 1173 Fax: +21 3 21 48 1454

Czech Republic Netvorice

Tel: +420 317 78 9313 Fax: +420 317 78 9314

France

Baudemont Tel: +33 385 28 2589 Fax: +33 385 28 0430

Cergy Tel: +33 130 31 3150 Fax: +33 130 38 6085

Decines Tel: +33 472 81 5000 Fax: +33 472 81 5010

Germany Langenfeld Tel: +49 21 73 8909-0 Fax: +49 21 73 8909 30

Hungary Budapest Tel: +36 13 39 8622 Fax: +36 13 39 8622

Italy

Parabiago Tel: +390 331 49 3311 Fax: +390 331 49 3330 Europe, Middle East, Africa

Ecully, France Tel: +33 472 18 2020 Fax: +33 472 18 2000

Netherlands

Tel: +31 76 578 3999

Fax: +31 76 578 3978

Tel: +48 22 843 3824

Fax: +48 22 843 3471

Tel: +351 229 69 8840 Fax: +351 229 69 8848

Tel: +351 212 109 340

Fax: +351 212 109 349

Tel: +7 495 641 2359

Fax: +7 495 641 2358

Tel: +971 4 3381 861

Fax: +971 4 3382 343

Tel: +44 1 895 43 0053

Fax: +44 1 895 45 9500

Tel: +44 191 522 2000

Fax: +44 191 522 2052

Asia - Pacific

Tel: +61 3 9 336 1300

Fax: +61 3 9 336 1322

Tel: +61 2 9 896 4433

Fax: +61 2 9 896 3122

Breda

Poland

Warsaw

Portugal

Alfena

Lisbon

Russia

Moscow

U.A.E.

Dubai

U. K.

Middlesex

Sunderland

Australia

Melbourne

Sydney

Asia – Pacific

Shanghai, China Tel: +86 21 51113579 Fax: +86 21 51113578

Singapore Tel: +65 6264 1188 Fax: +65 6862 4142

China

Beijing Tel: +86 10 58674761 Fax: +86 10 58674760 Xi'an Tel: +86 29 87891465 Fax: +86 29 87884504

Korea Seoul Tel: +82 2 3439 0400 Fax: +82 2 3439 0405

Philippines Makati City Tel: +63 2 844 9437 Fax: +63 2 844 4712

Factories

Brazil Alphaville

China Zhangjiagang

France Charlieu La Clayette Moulins

Germany Wilhelmshaven

India Calcutta

^{Pune} Italy

Niella Tanaro Portugal

Baltar Fânzeres

Slovakia _{Saris}

U.S.A. Manitowoc Port Washington Shady Grove



Constant improvement and engineering progress make it necessary that we reserve the right to make specification, equipment and price changes without notice. Illustrations shown may include optional equipment and accessories, and may not include all standard equipment.

©2008 MANITOWOC Printed in USA Form No. 3300 Series Part No. 08-006 / 0208 / 2M

