





Rough Terrain Hydraulic Crane

features





The RT535E incorporates a rectangular boom shape made from 100k.s.i. steel which eliminates weight and improves capacity compared to conventional shapes.



Rounded steel cab design provides aesthetic appeal.



New look dash control panel designed to offer a less cluttered look while still offering full instrumentation.



Cummins QSB 5.9L diesel engine provides plenty of power at the jobsite.



Max. tip height of 154 ft. (47.0 m) w/45 ft. (13.7 m) tele. extension







specifications

Superstructure

Boom

32 ft. - 102 ft. (9.8 m - 31.0 m) four-section, synchronized full power boom. Maximum tip height: 110 ft. (33.6 m).

* Optional Fixed Swingaway Extension

26 ft. (7.9 m) offsettable swingaway extension. Offsets 0° and 30°. Stows alongside base boom section. Maximum tip height: 135 ft. (41.1 m).

*Optional Telescopic Swingaway Extension

26 ft. - 45 ft. (7.9 m - 13.7 m) offsettable telescoping swingaway extension. Offsets at 0° and 30°. Stows alongside base boom section.

Maximum tip height: 154 ft. (47.0 m).

🔳 Boom Nose

Four nylatron sheaves mounted on heavy duty tapered roller bearings with removable pin-type rope guards. Quick reeve type boom nose.

Boom Elevation

One double-acting hydraulic cylinder with integral holding valve provides elevation from -3° to +78°.

Load Moment & Anti-Two Block System

Standard "Graphic Display" load moment and anti-two block system with audio-visual warning and control lever lockout. These systems provide electronic display of boom angle, length, radius, tip height, relative load moment, maximum permissible load, load indication and warning of impending two-block condition. The standard Work Area Definition System allows the operator to pre-select and define safe working areas. If the crane approaches the pre-set limits, audio-visual warnings aid the operator in avoiding job-site obstructions.

🖉 Cab

Full-vision, all-steel fabricated with acoustical lining and tinted safety glass throughout. Deluxe seat incorporates armrest mounted electric dual-axis controllers. Dash panel incorporates gauges for all engine functions. Other standard features include: tilt steering wheel, hot water heater, cab circulating air fan, sliding side and rear windows, sliding skylight with electric wiper and sunscreen, electric windshield wash/wipe, fire extinguisher and seat belt.

t Swing

Single speed, planetary swing drive with foot applied multi-disc wet brake. Spring applied, hydraulically released swing brake. Single position mechanical house lock, operated from cab. Maximum speed: 2.0 RPM.

Counterweight

9,920 lbs. (4 500 kg). Pinned to superstructure.



Two main pumps ([1] piston and [1] gear) with a combined capacity of 83.6 GPM (316.5 LPM).

Maximum operating pressure: 4,000 PSI (275.7 bar). Three section pressure compensated valve bank. Return line type filter with full flow by-pass protection and service indicator. Replaceable cartridge with micron filtration rating of 5/12/16. 104.6 gallon (396 L) hyd. reservoir. System pressure test ports.

HOIST SPECIFICATIONS (HP15C-17G) Main and Auxiliary Hoist

Planetary reduction with automatic spring applied multi-disc wet brake. Electronic hoist drum rotation indicators, and hoist drum cable followers.

Maximum Single Line Pull:

| 1st layer: | 11,640 lbs. (5 280 kg) |
|------------|------------------------|
| 3rd layer: | 9,530 lbs. (4 323 kg) |
| 5th layer: | 8,060 lbs. (3 656 kg) |

Maximum Permissible Line Pull: 11,640 lb. (5 280 kg) with 6x37 class rope 11,640 lb. (5 280 kg) with 35x7 class rope

Maximum Single Line Speed: 445 FPM (136 m/min)

Rope Construction: 6x36 EIPS IWRC, Special Flexible 35x7 Flex-X, Rotation Resistant

| Rope Diameter: | 5/8 in. (16 mm) |
|---|--|
| Rope Length: Main Hoist: Auxiliary Hoist: | 450 ft. (137.0 m) 450 ft. (137.0 m) |
| Maximum Rope Stowage: | 596 ft. (181.0 m) |

*Denotes optional equipment





specifications



Carrier

🖫 Chassis

Box section frame fabricated from high-strength, low alloy steel. Front/rear towing and tie down lugs.

Uutrigger System

Four hydraulic telescoping single-stage double box beam outriggers with inverted jacks and integral holding valves. Three position setting, 0%, 50% and fully extended. All steel fabricated, quick release type outrigger floats, 14.25 in. (362 mm) square.

Maximum outrigger pad load: 58,000 lbs. (26 308 kg)

Utrigger Controls

Controls and crane level indicator located in cab.

Engine (Tier II)

Cummins QSB 5.9L diesel, six cylinders, 155 bhp (116 kW) (Gross) @ 2,500 RPM. Maximum torque: 440 ft. lbs. (597 Nm) @ 1,500 RPM.

Fuel Tank Capacity

58 gallons (219.5 L)

Transmission

Range-shift 6 speed (3 speeds x 2 range, both forward & reverse). Front axle disconnect for 4×2 travel.

F Electrical System

Two 12 V - maintenance free batteries. 12 V starting and lighting. Battery disconnect. CanBus Diagnostic system.

4 x 4

T Steering

 Fully independent power steering:

 Front:
 Full hydraulic steering wheel controlled.

 Rear:
 Full hydraulic switch controlled.

 Provides infinite variations 4 main steering modes: front only, rear only, crab and coordinated. Rear steer indicator.

 Turning radius:
 19 ft. (5.8 m)



Rear:

Front: Drive/steer with differential and planetary reduction hubs rigid mounted to frame.

hubs pivot mounted to frame.



(I+I) Oscillation Lockouts

Automatic full hydraulic lockouts on rear axle permits 10 in. (25.4 cm) oscillation only with boom centered over the front.

Drive/steer with differential and planetary reduction

O Brakes

Full hydraulic split circuit operating on all wheels. Springapplied, hydraulically released parking brake mounted on front axle.

```
Std. 20.5 x 25 - 24 bias ply, General
```

Lights

Full lighting including turn indicators, head, tail, brake and hazard warning lights.

🕑 Maximum Speed

25 MPH (40 kph) @ 2500 r.p.m.



119% (at engine stall)

Based on 61,640 lb. [27 960 kg] GVW) 20.5 x 25 tires, 102 ft. (31.0 m) main boom, plus 45 ft. (13.7 m) telescopic swingaway, 9,920 lb. (4 500 kg) counterweight, 35T hookblock and 7.5T headache ball.

Miscellaneous Standard Equipment

Full width steel fenders, full length steel decking with anti-skid, dual rear view mirrors, hook-block tie down, electronic back-up alarm, light package, front stowage well, tachometer/hourmeter, rear wheel position indicator, 36,000 BTU hot water cab heater, hoist mirrors, engine distress A/V warning system, front/rear tie down and tow lugs, coolant sight lever indicator.

***Optional Equipment**

* AUXILIARY HOIST PACKAGE (includes Model HP15C-17G auxiliary hoist with electronic hoist drum rotation indicator, hoist drum cable follower, 450 ft. (137.0 m) of 5/8 in. (16 mm) 35 x 7 class wire rope and auxiliary single sheave boom nose.
*AUXILIARY LIGHTING PACKAGE (includes cab mounted amber flashing light, hoist mounted work light, and dual base boom mounted floodlights).
*LMI light bar (in cab)
*Air conditioning (28,500 BTU)
*360° NYC style mechanical swing lock
*Rear pintle hook
*Cab controlled cross axle differential locks (front and rear)
*PAT data logger down-load kit
*Rubber mat for stowage trough

*Denotes optional equipment





dimensions







Weights

| | Gross | Front | Rear |
|---|--------------|--------------|--------------|
| | (lbs. / kg.) | (lbs. / kg.) | (lbs. / kg.) |
| Basic Machine including 102 ft. (31.0m) main | | | |
| boom, main hoist with 450 ft. (137.0m) of | | | |
| rope, full counterweight + IPO, 7.5 T (6.8mt) | 59,135 | 27,717 | 31,418 |
| headache ball, and 35T (35mt) hookblock: | (26 823 kg) | (12 572 kg) | (14 251 kg) |
| | | | |
| Add: Auxiliary Hoist + 450 ft. (137.0m) of | | | |
| 35 x 7 hoist cable and auxiliary boom nose | 59,634 | 27,886 | 31,748 |
| ILO IPO C/W | (27 050 kg) | (12 649 kg) | (14 400 kg) |
| | | | |
| ADD: Fixed 26 ft. (7.9m) offsttable boom | 61,170 | 30,655 | 30,515 |
| extension + extension hangers | (27 746 kg) | (13 905 kg) | (13 842 kg) |
| OR | | | |
| ADD: 26 ft 45 ft. (7.9 - 13.7m) telescopic | 61,640 | 31,459 | 30,181 |
| boom extension + extension hangers | (27 960 kg) | (14 269 kg) | (13 690 kg) |







RT535E load chart

| 32 - 102 ft. | 9,920 lbs | 100% | Q 360° | | | | | | |
|----------------------------------|---|--|------------------|------------------|------------------|------------------|------------------|-----------------|---|
| | 0,010 120 | 20' spread | | | | | | | _ |
| | | | | F | ounds | | | | 7 |
| Feet | 32 | 40 | 50 | 60 | 70 | 80 | 90 | 102 | |
| 10 | 70,000 (65) | 50,100 (70.5) | *47,000 (76) | | | | | | |
| 12 | 56,500 (60.5) | 50,100 (67) | 47,000 (72) | *46,000 (76) | | | | | |
| 15 | 46,500 (54) | 47,350 (62) | 46,000 (68.5) | 43,000 (72.5) | *38,000 (76) | | | | |
| 20 | 33,800 (41) | 34,000 (53.5) | 34,000 (62) | 34,000 (67.5) | 30,000 (71) | 28,000 (74) | *22,000 (76) | | |
| 25 | 25,000 (20) | 26,000 (43) | 26,300 (55) | 26,000 (62) | 25,000 (66.5) | 23,500 (70) | 21,000 (73) | *18,000 (76) | |
| 30 | | 20,000 (29.5) | 20,500 (47.5) | 20,500 (56) | 21,000 (62) | 20,000 (66) | 18,000 (69.5) | 16,300 (72) | |
| 35 | - | | 16,000 (38.5) | 16,500 (50) | 17,500 (57) | 17,000 (62) | 15,500 (66) | 14,400 (69) | |
| 40 | | _ | 13,000 (26.5) | 13,500 (43) | 13,500 (52) | 14,000 (58) | 13,100 (62) | 12,600 (66) | |
| 45 | | | | 11,200 (35) | 10,750 (46) | 11,500 (53.5) | 11,250 (58.5) | 11,000 (63) | |
| 50 | | | | 9,000 (24) | 9,000 (40) | 9,500 (48.5) | 9,000 (54.5) | 9,300 (59.5) | _ |
| 55 | | | | | 7,300 (32.5) | 8,000 (43.5) | 7,500 (50.5) | 7,800 (56.5) | |
| 60 | | | | | 6,200 (22.5) | 6,600 (37.5) | 6,300 (46) | 6,450 (52.5) | |
| 65 | | | | | | 5,500 (30.5) | 5,300 (41) | 5,300 (49) | |
| 70 | | | | | | 4,500 (21) | 4,500 (35.5) | 4,400 (45) | |
| 75 | | | | | | | 3,800 (29) | 3,800 (40.5) | |
| 80 | | | | | | | 3,200 (20) | 3,200 (35.5) | |
| 85 | | | | | | | | 2,600 (29.5) | |
| 90 | | | | | | | | 2,200 (22.5) | - |
| 95 | | | | | | | | 1,600 (9) | |
| Minimum boom a Maximum boom I | angle (°) for indicate length (ft) at 0° boo | ed length (no load) m angle (no load) | | | | | | 0 102 | |

m boom length (π) at 0° boom ar

NOTE: () Boom angles are in degrees. #LMI operating code. Refer to LMI manual for operating instructions. *This capacity is based on maximum boom angle.

| Lifting Capacities at Zero Degree Boom Angle | | | | | | | | |
|--|--------|--------|--------|--------|--------|--------|--------|--------|
| Boom Main Boom Length in Feet | | | | | | | | |
| Angle | 32 | 40 | 50 | 60 | 70 | 80 | 90 | 102 |
| ٥° | 24,000 | 17,000 | 11,000 | 8,000 | 5,000 | 3,500 | 2,300 | 1,250 |
| • | (26) | (33.8) | (43.8) | (53.8) | (63.8) | (73.8) | (83.8) | (95.5) |
| | | | | | | | | |

NOTE: () Reference radii in feet.

A6-829-104120

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

GROVE.

RT535E load chart



NOTE: () Boon angles are in degrees. #LMI operating code. Refer to LMI manual for instructions. *This capacity based on maximum boom angle. *'26 fit capacities are also applicable to fixed offsettable ext. However, the LMI codes will change to #0051 and #0053 for 0° and 30° offset, recording the set of the

respectively.



1. All capacities above the bold line are based on structural strength of boom extension

Crane Works, L. 1-877-MAX-LIF

- 2. 26 ft. and 45 ft. boom extension lengths may be used for single line lifting service.
- Radii listed are for a fully extended boom with the boom extension 3. erected. For main boom lengths less than fully extended, the rated loads are determined by boom angle. Use only the column which corresponds to the boom extension length and offset for which the machine is configured. For boom angles not shown, use the rating of the next lower boom angle.

WARNING: Operation of this machine with heavier loads than the capacities listed is strictly prohibited. Machine tipping with boom extension occurs rapidly and without advance warning.

- 4. Boom angle is the angle above or below horizontal of the longitudinal axis of the boom base section after lifting rated load.
- 5. Capacities listed are with outriggers fully extended and vertical jacks set only.
- When lifting over the main boom nose with 26 ft. or 45 ft. extension 6. erected, the outriggers must be fully extended or 50% extended (14' spread).



THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

A6-829-104123

GROVE



RT535E load charts

| 32 - 102 ft. | 9,920 lbs | 50% | Q 360° | | | | | | |
|--------------|--|-------------------|------------------|------------------|------------------|-----------------|------------------|-----------------|---|
| | 9,920 IDS | 50% 14' spread | 360° | | | | | | _ |
| Pounds | | | | | | | | | |
| Feet | 30 | 40 | 50 | 60 | 70 | 80 | 90 | 102 | |
| 10 | 68,700 (65) | 50,100 (70.5) | *47,000 (76) | | | | | | |
| 12 | 56,500 (60.5) | 50,100 (67) | 47,000 (72) | *46,000 (76) | | | | | |
| 15 | 46,100 (54) | 44,200 (62) | 41,750 (68.5) | 39,500 (72.5) | *37,550 (76) | | | | |
| 20 | 26,850 (41) | 27,550 (53.5) | 27,050 (62) | 25,950 (67.5) | 24,950 (71) | 24,000 (74) | *22,000 (76) | | |
| 25 | 17,450 (20) | 18,050 (43) | 18,650 (55) | 18,600 (62) | 18,050 (66.5) | 17,450 (70) | 16,950 (73) | *16,300 (76) | |
| 30 | . , | 12,700 (29.5) | 13,200 (47.5) | 13,500 (56) | 13,550 (62) | 13,250 (66) | 12,900 (69.5) | 12,500 (72) | |
| 35 | | | 9,700 (38.5) | 10,050 (50) | 10,200 (57) | 10,250 (62) | 10,100 (66) | 9,810 (69) | |
| 40 | | | 7,260 (26.5) | 7,570 (43) | 7,770 (52) | 7,910 (58) | 7,940 (62) | 7,810 (66) | |
| 45 | | | () | 5,750 (35) | 5,940 (46) | 6,110 (53.5) | 6,180 (58.5) | 6,200 (63) | |
| 50 | | | | 4,350 (24) | 4,540 (40) | 4,700 (48.5) | 4,790 (54.5) | 4,860 (59.5) | |
| 55 | | | | () | 3,430 (32.5) | 3,590 (43.5) | 3,690 (50.5) | 3,780 (56.5) | |
| 60 | | | | | 2,530 (22.5) | 2,680 (37.5) | 2,790 (46) | 2,890 (52.5) | |
| 65 | | | | | (| 1,940 (30.5) | 2,040 (41) | 2,150 (49) | |
| 70 | | | | | | 1,310 (21) | 1,420 (35.5) | 1,530 (45) | |
| | ngle (°) for indicated length (ft.) at 0° boom | | | | | 0 | 20 80 | 36 | |

Maximum boom length (ft.) at 0° boom angle (no load) NOTE: () Boom angles are in degrees. #LMI operating code. Refer to LMI manual for operating instructions.

| * I his capacity is | based on maximum | boom angle. | | | | |
|--|----------------------|-------------|--------|--------|--------|--------|
| Lifting Capacities at Zero Degree Boom Angle | | | | | | |
| Boom Main Boom Length in Feet | | | | | | |
| Angle | 32 | 40 | 50 | 60 | 70 | |
| ٥° | 16,100 | 9,970 | 5,850 | 3,490 | 1,950 | |
| 0 | (26) | (33.8) | (43.8) | (53.8) | (63.8) | |
| NOTE: () Refer | rence radii in feet. | | | | | A6-829 |

RT535E

GROVE.

load charts





NOTE: () Boom angles are in degrees. #LMI operating code. Refer to LMI manual for instructions. *This capacity based on maximum boom angle. *26 ft. capacities are also applicable to fixed offsettable ext. However, the LMI codes will change to #4051 and #4053 for 0° and 30° offset, recordingly. respectively.

BOOM EXTENSION CAPACITY NOTES:

- 1. All capacities above the bold line are based on structural strength of boom extension.
- 2. 26 ft. and 45 ft. boom extension lengths may be used for single line lifting service.
- 3. Radii listed are for a fully extended boom with the boom extension erected. For main boom lengths less than fully extended, the rated loads are determined by boom angle. Use only the column which corresponds to the boom extension length and offset for which the machine is configured. For boom angles not shown, use the rating of the next lower boom angle.

WARNING: Operation of this machine with heavier loads than the capacities listed is strictly prohibited. Machine tipping with boom extension occurs rapidly and without advance warning.

- 4. Boom angle is the angle above or below horizontal of the longitudinal axis of the boom base section after lifting rated load.
- 5. Capacities listed are with outriggers properly extended and vertical jacks set only.
- 6. When lifting over the main boom nose with 26 ft. or 45 ft. extension erected, the outriggers must be fully extended or 50% extended (14' spread).



THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

A6-829-104124

GROVE

| 32 - 60 ft . | 9,920 lbs | C) Stationary | Q 360° | | | |
|-------------------------------------|---|-------------------------|------------------|------------------|--|--|
| | | | Pounds |] | | |
| | | #900 | 5 | | | |
| Feet | | Main Boom Leng | | | | |
| | 32 | 40 22.950 | 50 | 60 | | |
| 10 | 22,950 (65) | (70.5) | *23,000 (76) | | | |
| 12 | 21,150 (60.5) | 21,850 (67) | 21,600 (72) | | | |
| 15 | 14,300 (54) | 15,300 (62) | 15,950 (68.5) | 13,850 (72.5) | | |
| 20 | 8,330 (40.5) | 9,180 (53.5) | 9,710 (62) | 9,940 (67.5) | | |
| 25 | 5,100 (20) | 5,880 (43) | 6,260 (55) | 6,530 (62) | | |
| 30 | | 3,810 (29.5) | 4,100 (47) | 4,360 (56) | | |
| 35 | | | 2,630 (38) | 2,870 (50) | | |
| 40 | | | 1,550 (26) | 1,800 (43) | | |
| Minimum boon indicated lengt | n angle (°) for h (no load) | | 25 | 42 | | |
| Maximum boor 0° boom angle | n length (ft.) at | | | 40 | | |
| NOTE: () Boor #LMI operating | m angles are in de g code. Refer to LN | grees. Il manual for | | | | |
| operating instri *This capacity | uctions. is based on maxim | um boom angle. | | | | |
| Lifting Capacities at 0° Boom ?ngle | | | | | | |
| Boom Angle | Main 32 | Boom Length in 40 | Feet | | | |
| 0° | 4,600 | 2,700 | - | | | |
| U | (26) | (33.8) | | | | |
| NOTE: () Refe | rence radii in feet. | | | A6-829-104125 | | |

| | loa | | nart | S |
|-----------|--|--------------|---------------------|-----------|
| 9,920 lbs | Pick & Carr (Max. 2.5 MF 20.5 x 25 O 16 x 25 tire | PH) Ove R | Centered r Front | 1 |
| | | Pounds | | \supset |
| | #90 | 06 | | |
| | Main Boom Le | ngth in Feet | | |
| 32 | 40 | 50 | 60 | |

.1

| Feet | 32 | 40 | 50 | 60 | | | | |
|---|-------------------------------------|----------------------|------------------|------------------|--|--|--|--|
| 10 | 26,850 (64.5) | 27,250 (70) | | | | | | |
| 12 | 23,150 (60.5) | 23,500 (67) | | | | | | |
| 15 | 18,800 (53.5) | 19,200 (62) | 19,450 (68) | | | | | |
| 20 | 13,600 (40.5) | 14,150 (53) | 14,500 (61.5) | 14,550 (67) | | | | |
| 25 | 10,050 (19.5) | 10,600 (42.5) | 11,100 (54.5) | 11,200 (61.5) | | | | |
| 30 | | 8,040 (29) | 8,570 (47) | 8,740 (56) | | | | |
| 35 | | | 6,650 (38) | 6,810 (49.5) | | | | |
| 40 | | | 5,130 (26) | 5,300 (42.5) | | | | |
| 45 | | | | 4,090 (34.5) | | | | |
| 50 | | | | 3,090 (23.5) | | | | |
| Minimum boom length (no load) | angle (°) for indic | ated | | 0 | | | | |
| Maximum boom length (ft.) at 0° boom angle (no load) 60 NOTE: () Boom angles are in degrees. #LMI operating code. Refer to LMI manual for operating instructions. | | | | | | | | |
| | Lifting Capacities at 0° Boom Angle | | | | | | | |
| Boom Angle | Main 32 | Boom Length in 40 | Feet 50 | 60 | | | | |
| 0° | 9,480 (26) | 6,530 (33.8) | 4,190 (43.8) | 2,440 (53.8) | | | | |

| , | 32 | 40 | 50 | |
|----|---------------|-----------------|-----------------|--|
| 0° | 9,480 (26) | 6,530 (33,8) | 4,190 (43.8) | |
| | | | | |

NOTE: () Reference radii in feet.

32 - 60 ft.

G

A6-829-104126

BOOM EXTENSION CAPACITY NOTES:

- 1. Capacities are in pounds and do not exceed 75% of tipping loads as determined by test in accordance with SAE J765.
- 2. Capacities are applicable to machines equipped with 20.5x25 (24 ply) tires at 75 psi cold inflation pressure, and 16.00x25 (28 ply) tires at 100 psi cold inflation pressure.
- 3. Capacities appearing above the bold line are based on structural strength and tipping should not be relied upon as a capacity limitation.
- 4. Capacities are applicable only with machine on firm level surface.
- 5. On rubber lifting with boom extensions not permitted.
- 6. For pick and carry operation, boom must be centered over front of machine, mechanical swing lock engaged and load restrained from swinging. When handling loads in the structural range with capacities close to maximum ratings, travel should be reduced to creep speeds.
- 7. Axle lockouts must be functioning when lifting on rubber.
- 8. All lifting depends on proper tire inflation, capacity and condition. Capacities must be reduced for lower tire inflation pressures. See lifting capacity chart for tire used. Damaged tires are hazardous to safe operation of crane.
- 9. Creep not over 200 ft. of movement in any 30 minute period and not exceeding 1 mph.

535

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.







| | 32 - 102 ft. | 9,920 lbs | 0% 7.8' spread | Q 360° | | | | | |
|----|---------------------------------|---|--------------------------|------------------|------------------|-----------------|-----------------|-----------------|-----------------|
| 12 | | | | | P | ounds | | | |
| | Feet | 30 | 40 | 50 | 60 | 70 | 80 | 90 | 102 |
| | 10 | 37,650 (65) | 35,900 (70.5) | *33,600 (76) | | _ | | | |
| | 12 | 28,900 (60.5) | 28,000 (67) | 26,550 (72) | *25,100 (76) | | _ | | |
| | 15 | 20,700 (54) | 20,300 (62) | 19,750 (68.5) | 18,800 (72.5) | *18,000 (76) | | | _ |
| | 20 | 12,300 (41) | 12,800 (53.5) | 12,850 (62) | 12,550 (67.5) | 12,100 (71) | 11,650 (74) | *11,250 (76) | |
| | 25 | 7,760 (20) | 8,240 (43) | 8,670 (55) | 8,700 (62) | 8,530 (66.5) | 8,290 (70) | 8,030 (73) | 7,710 (76) |
| | 30 | . , | 5,400 (29.5) | 5,810 (47.5) | 6,120 (56) | 6,060 (62) | 5,940 (66) | 5,820 (69.5) | 5,590 (72) |
| | 35 | | | 3,870 (38.5) | 4,170 (50) | 4,290 (57) | 4,220 (62) | 4,160 (66) | 4,050 (69) |
| | 40 | | | 2,470 (26.5) | 2,760 (43) | 2,940 (52) | 2,930 (58) | 2,900 (62) | 2,820 (66) |
| | 45 | | | . , | 1,690 (35) | 1,850 (46) | 1,910 (53.5) | 1,910 (58.5) | 1,860 (63) |
| | 50 | | | | | 1,000 (40) | 1,100 (48.5) | 1,110 (54.5) | 1,080 (59.5) |
| | Minimum boom a length (no load) | ngle (°) for indicated | | | 0 | 33 | 44 | 51 | 57 |
| | angle (no load) | ength (ft.) at 0° boom angles are in degrees. ode Refer to I Milmar | ual for operating instru | ictions | | | 60 | | |

*This capacity is based on maximum boom angle.

Lifting Capacities at Zero Degree Boom Angle Main Boom Length in Feet Boom Angle 32 40 50 3,870 (33.8) 7,060 (26) 1,640 (43.8) 0° A6-829-104122

NOTE: () Reference radii in feet.



THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.

GROVE.



Weight Reductions for Load Handling Devices

| 26 ft. Offsettable Boom Extension | Pounds |
|--|------------------------|
| *Erected - | 2,750 |
| | |
| 26 ft45 ft. Tele. Boom Extension | Pounds |
| 26 ft45 ft. Tele. Boom Extension *Erected (Retracted) - | Pounds 3,850 |

*Reduction of main boom capacities

| Auxiliary Boom Nose | Pounds | |
|-------------------------------|--------|--|
| | 105 | |
| Hookblocks and Headache Balls | Pounds | |
| 35 Ton, 3 Sheave | 623 + | |
| 35 Ton, 4 Sheave (CE) | 774 + | |
| 7.5 Ton Overhaul Ball | 369 + | |

+Refer to rating plate for actual weight.

When lifting over swingaway and/or jib combinations, deduct total weight of all load handling devices reeved over main boom nose directly from swingaway or jib capacity.

NOTE: All load handling devices and boom attachments are considered part of the load and suitable allowances MUST BE MADE for their combined weights. Weights are for Grove furnished equipment.

load handling



Line Pulls and Reeving Information

| Hoists | Cable Specs | Permissible Line Pulls | Nominal Cable Length |
|-------------|--|---------------------------|-------------------------|
| Main & Aux. | 5/8" (16 mm) Flex-X35 (35x7) Rotation Resistant (non-rotating) Min. Breaking Str. 61,200 lb. | 11,640 lb. | 450 ft. |
| Main | 5/8" (16 mm) 6x37 Class EIPS, IWRC Special Flexible Min. Breaking Str. 41,200 lb. | 11,640 lb. | 450 ft. |

Hoist Performance

| Wire Rope Layer | Hoist Line Pulls Available Ib.* | | n Rope city (ft.) Total | |
|-----------------------|---------------------------------------|-----|-------------------------------|--|
| 1 | 11,640 | 77 | 77 | |
| 2 | 10,480 | 85 | 162 | |
| 3 | 9,530 | 94 | 256 | |
| 4 | 8,730 | 102 | 358 | |
| 5 | 8,060 | 111 | 469 | |
| 6 | 7,490 | 119 | 588 | |

*Max. lifting capacity: 6x37 class = 11,640 lb. 35x7 class = 11,640 lb.

Working Area Diagram



Bold lines determine the limiting position of any load for operation within working areas indicated.

THIS CHART IS ONLY A GUIDE AND SHOULD NOT BE USED TO OPERATE THE CRANE. The individual crane's load chart, operating instructions and other instructional plates must be read and understood prior to operating the crane.



535

















Manitowoc Crane Group - Americas Manitowoc, Wisconsin Facility Tel: [Int + 001] 920 684 6621 Fax: [Int + 001] 920 683 6277 Shady Grove, Pennsylvania Facility Tel: [Int + 001] 717 597 8121 Fax: [Int + 001] 717 597 4062 Manitowoc Crane Group - EMEA Europe Middle East & Africa Tel: [Int + 33] (0) 191 565 6281 Fax: [Int + 33] (0) 4 72 18 20 20 Manitowoc Crane Group - UK Europe Middle East & Africa Tel: [Int + 44] (0) 191 565 6281 Fax: [Int + 44] (0) 191 564 0442 Manitowoc Crane Group - Germany (Sales, Parts & Service) Tel: [Int + 49](0) 2173 8909 0 Fax: [Int + 49] (0) 2173 8909-30 Manitowoc Crane Group - France France & Africa (Sales, Parts & Service) Tel: [Int + 33] (0) 1 303 13150 Fax: [Int + 33] (0) 1 303 86085 Manitowoc Crane Group - Netherlands (Sales, Parts & Service) Tel: [Int + 31] (0) 76 578 39 99 Fax: [Int + 31] (0) 76 578 39 78 Manitowoc Crane Group - Italy Italy & Southern Europe (Sales, Parts & Service) Tel: [Int + 39] (0) 331 49 33 11 Fax: [Int + 39] (0) 331 49 33 30 Manitowoc Crane Group - Portugal Portugal & Spain (Sales, Parts & Service) Tel: [Int + 351] (0) 22 968 08 89 Fax: [Int + 351] (0) 22 968 08 97 Manitowoc Crane Group - Singapore Asia/Pacific excl China (Sales, Parts & Service) Tel: [Int + 65] 6861 1733 Fax: [Int + 65] 6862 4040 / 4142 Manitowoc Crane Group - Shanghai China (Sales, Parts & Service) Tel: [Int + 86] (0) 21 64955555 Fax: [Int + 86] (0) 2164852038 Manitowoc Crane Group - Beijing China (Sales, Parts & Service) Tel: [Int + 86] (0) 10 646 71690 Fax: [Int + 86] (0) 10 646 71691 Manitowoc Crane Group - Middle East (Sales) Tel: [Int + 971] (0) 4 348 4478 Fax: [Int + 971] (0) 4 348 4478 (Parts & Service) Tel: [Int + 973] (0) 9 660 899 Fax: [Int + 973] (0) 2 707 740

Distributed By:



www.manitowoccranegroup.com



Constant improvement and engineering progress make it necessary that we reserve the right to make specification, equipment, and price changes without notice. Illustrations shown may include optional equipment and accessories, and may not include all standard equipment.